

**Assembly Instruction for code 137**

- Check the right position of the plastic profiles and make a trace on the wall.
- Make a hole on the wall and on the plastic flaps .



- Install on the right place by screws .
- Straight the cord in order to get a perfect assembly.
- Clean the set .

